HIDDEN GLASS


隐藏式滑动系统

适用于玻璃门




By SISCO SISTEM

KIT 1800-1150 V - MAX 80 KG
KIT 1800-1150/40 V - MAX 40 KG




配件明细


1805	Guida superiore regolabile *Adjustable upper truck*
02.PE350Z	Perno *Pin*
1898 DX-SX	Decelerante DX-SX (80kg) *Soft Closing Stopper R-L (80kg)*
1897 DX-SX	Decelerante DX-SX (40kg) *Soft Closing Stopper R-L (40kg)*
1810	Guida inferiore *Lower runner*
1806V	Carrello inferiore Vetro *Glass Lower truck*
1807	Pinza Vetro *Glass Clamp*
1813	Borchia Vetro *Glass Stud*
01.TT1800	Tappo terminale *End cover*
1820	Tappo terminale *End cover*
1821 DX-SX	Tappo Terminale DX-SX *End Cover R-L*
02.UXR635	Tassello *Dowel*
02.VTSC4540Z	Vite 4.5x40 *Screw 4.5x40*
1812	Labbro Parapolvere L=1150mm *Dust Lip L=1150mm*
1800	Profilo superiore L=1150mm *Upper profile L=1150mm*
1808	Profilo inferiore L=1150mm *Lower profile L=1150mm*
1809	Copertura inferiore l=1150mm *Lower Cover L=1150mm*
1804	Copertura superiore L=1150mm *Upper Cover L=1150mm*




侧视图（无盖板）
Vertical section without cover




侧视图（有盖板）
Vertical section with cover




玻璃开孔图/ *Glass door drilling*




左开门示意图




右开门示意图




门完全开启安装时标准尺寸图
Standard dimensions for door with complete doorway opening




门不完全开启时标准尺寸图
Standard dimensions for door with partial doorway opening




上下导轨位置 / *Upper and lower guide position*




门完全开启安装时阻尼缓冲位置 / *Soft closing position for complete opening*



门不完全开启安装时阻尼缓冲位置 / *Soft closing position for partial opening*




自激活装置 / *Automatic-self activating device*




调节指导 / *Assembly instructions*


① 将上导轨的中心与门的中心线对齐，如下图所图，检查防脱扣是否被激活。
Fit the center line of the door close to the upper truck previously fastened to the wall. Check that the clasp is not triggered, as shown in the figures below.




② 固定下滚轮ART.1810，将门装在上导轨。
Position the door astride the runner ART. 1810 lying the lower wheels on the ground.




③ 通过使型材靠在上支架的滚轮上，使门处于垂直位置。将门一直压在上支架上，直到组装结束。
Put the door in a vertical position, placing its profile on the wheels of the upper truck. Keep the door pushed against the upper truck till the end of the assembly.







④ 拉开防脱扣
Pull the lever of the clasp.




⑤ 防脱扣自动放在上部型材上。
The clasp will automatically lie on the upper profile.






⑥ 拧紧壁挂支架的高度调节螺丝。
Fasten the screw for the adjustment of wall bracket height.
向上拧摇杆，使滚轮靠近型材。
The rocker arm rises, moving the wheels closer to the profile.
当防脱扣发出“ 喀哒 ”声时，停止拧紧。
When the clasp makes a loud “Click”, stop fastening.




Regolazione allineamento porta/muro / *Door/Wall alignment adjustment*




SE LA PORTA NON È PARALLELA AL MURO
SVITARE LE 2 APPOSITE VITI DI BLOCCAGGIO

IF THE DOOR IS NOT ALIGNED WITH THE WALL
LOOSEN THE FIXING SCREWS



ALLINEARE LA PORTA AL MURO MANUALMENTE
ALIGN MANUALLY THE DOOR WITH THE WALL



BLOCCARE L'ALLINEAMENTO SERRANDO LE DUE VITI DI FISSAGGIO
LOCK THE ALIGNMENT SCREWING THE FIXING SCREWS



购买咨询
北京中意信诚贸易有限公司
TEL：13910114747（微信同号）
WEB: wwww.china-era.com