HIDDEN


隐藏式滑动系统


适用于木门



By SISCO SISTEM

KIT 1800-1150 - MAX 80 KG
KIT 1800-1150/40 - MAX 40 KG






配件明细


1805	Guida superiore regolabile
	Adjustable upper truck
1806	Carrello inferiore
	Lower truck
0106	Guida inferiore
	Lower runner
01.TT1800	Tappo terminale
	End cover
1898 DX-SX	Decelerante DX-SX (80kg)
	Soft Closing Stopper R-L (80kg)
1897 DX-SX	Decelerante DX-SX (40kg)
	Soft Closing Stopper R-L (40kg)
02.PE350Z	Perno
	Pin
02.VTSC3515Z	Vite 3.5x15
	Screw 3.5x15
02.VTSC3540Z	Vite 3.5x40
	Screw 3.5x40
02.VTSC4540Z	Vite 4.5x40
	Screw 4.5x40
02.UXR635	Tassello
	Dowel
1800	Profilo superiore L=1150mm
	Upper profile L=1150mm
0251	Profilo inferiore
	Lower profile

侧视图（不带踢脚线）
Vertical section without skirting board




H =	Y + 100
K =	10+S/2

侧视图（带踢脚线）
Vertical section with skirting board




H =	Y + 100	R =	踢脚线厚度
K =	10+S/2		*SKIRTING BOARD THICKNESS*




下导轨位置
Lower guide position

C = 109 mm	安装方式一 For door with through milling
C = 117.5 mm	安装方式二 For door with blind milling
D = 83 mm	安装方式一 For door with through milling
D = 91.5 mm	安装方式二 For door with blind milling



两种安装方式




安装方式一：

门板穿透，导轨明装，末端贴片。

安装方式二：


门板不穿透，导轨暗藏。

上导轨位置 / *Upper truck position*




A = 47 mm	安装方式一 For door with through milling	A = 55.5 mm	安装方式二 For door with blind milling
B = 54 mm	安装方式一 For door with through milling	B = 62.5 mm	安装方式二 For door with blind milling

安装方式一标准尺寸图
Standard dimensions for door with through milling




X	LARGHEZZA VANO / DOORWAY WIDTH
L	LARGHEZZA PORTA / DOOR WIDTH
Y	ALTEZZA VANO / DOORWAY HEIGHT
H	ALTEZZA PORTA / DOOR HEIGHT

安装方式一门开孔图
Door drilling with through milling




W	LUNGHEZZA PROFILO SUPERIORE / UPPER PROFILE LENGHT
J	LUNGHEZZA PROFILO INFERIORE / LOWER PROFILE LENGHT

安装方式二标准尺寸图
Standard dimensions for door with blind milling




X	LARGHEZZA VANO / DOORWAY WIDTH
L	LARGHEZZA PORTA / DOOR WIDTH
Y	ALTEZZA VANO / DOORWAY HEIGHT
H	ALTEZZA PORTA / DOOR HEIGHT

安装方式二门开孔图
Door drilling with blind milling




W	LUNGHEZZA PROFILO SUPERIORE / UPPER PROFILE LENGHT
J	LUNGHEZZA PROFILO INFERIORE / LOWER PROFILE LENGHT

自激活装置/*Automatic self activating device*




调节指导 /*Assembly instructions*


1
将上导轨的中心与门的中心线对齐，
如下图所图，
检查防脱扣是否被激活。
Fit the center line of the door close to the upper truck previously fastened to the wall. Check that the clasp is not triggered, as shown in the figures below.




2
固定下滚轮ART. 0106，
将门装在上导轨。
Position the door astride the runner ART. 0106 lying the lower wheels on the ground.




3 通过使型材靠在上支架的滚轮上，使门处于垂直位置。将门一直压在上支架上，直到组装结束。
Put the door in a vertical position, placing its profile on the wheels of the upper truck. Keep the door pushed against the upper truck till the end of the assembly.








4 拉开防脱扣
Pull the lever of the clasp.



5 防脱扣自动放在上部型材上。
The clasp will automatically lie on the upper profile.









6 拧紧壁挂支架的高度调节螺丝。
Fasten the screw for the adjustment of wall bracket height.
向上拧摇杆，使滚轮靠近型材。
The rocker arm rises, moving the wheels closer to the profile.
当防脱扣发出 “ 喀哒 ” 声时，停止拧紧。
When the clasp makes a loud “Click”, stop fastening.

门与墙平行调整 / *Door/Wall alignment adjustment*

7






如果门与墙不平行，则松开两个螺丝。

IF THE DOOR IS NOT ALIGNED WITH THE WALL LOOSEN THE FIXING SCREWS


8




手动将门与墙平行

ALIGN MANUALLY THE DOOR WITH THE WALL

9





拧紧两个固定螺丝

LOCK THE ALIGNMENT SCREWING THE FIXING SCREWS



购买咨询
北京中意信诚贸易有限公司
TEL：13910114747（微信同号）
WEB: wwww.china-era.com